Quiz

- 1. A geologic formation which cannot deliver appreciable quantity of water is called
 - I. AquiferII. AquicludeIII. AquifugeIV. Aquifuge
- 2. Fence diagrams depict
 - I. Stratigraphic data in three dimensions
 - II. Stratigraphic data in two dimensions
 - III. Location of strategic ground water measurements points
 - IV. Status of ground water recharge
- 3. To determine "net sown area"
 - I. Area sown more than once in the same year is counted once.
 - II. Area sown more than twice in the same year is counted twice.
 - III. Area sown more than once in the same year is counted as many time as it is sown.
 - IV. Area sown more than once and irrigated is counted.

Tutorial:

- 1. What is a piper diagram and what does it depict?
- 2. What are the various land use classes in the new classification being followed in India? List them.
- 3. What do you understand by time variant and time invariant ground water data? Give examples and use of each.