


DIGITAL COMMUNICATION

RECEIVER:



SCHEMATIC OF
DIGITAL COMM. RECEIVER

Sampled at T
 $T = \text{Symbol Duration}$

$$r(t) = y(t) * h(t)$$

impulse
response of
LTI System
or Receive
Filter

$$= \int_{-\infty}^{\infty} y(t-z) h(z) dz$$

convolution

Substitute in expression
for $r(t)$.

$$y(t) = x(t) + n(t)$$

Additive Noise
channel.

$$a_0 p(t) = x(t)$$

Symbol Pulse

For
simplicity

$$y(t) = a_0 p(t) + n(t)$$

$$r(t) = \int_{-\infty}^{\infty} (a_0 p(t-\tau) + n(t-\tau)) \times h(\tau) d\tau$$

Sampled at T

$$r(T) = \int_{-\infty}^{\infty} (a_0 p(T-\tau) + n(T-\tau)) \times h(\tau) d\tau$$

$$= \underbrace{a_0 \int_{-\infty}^{\infty} p(T-\tau) h(\tau) d\tau}_{\text{Signal Component}} + \underbrace{\int_{-\infty}^{\infty} n(T-\tau) h(\tau) d\tau}_{\text{Noise Component}}$$

How to choose filter $h(\tau)$?

Design

- Objectives:
1. Maximize Signal Power
 2. Minimize Noise Power
- = Maximize Signal to Noise power Ratio (SNR)

$$\boxed{\text{SNR} = \frac{\text{Signal Power}}{\text{Noise Power}}}$$

Fundamental Quantity
For analysis of
performance of a
communication system.

Signal: $a_0 \cdot \int_{-\infty}^{\infty} p(t-\tau) h(\tau) d\tau$

$$\begin{aligned} \text{Signal Power} &= E \left\{ \left| a_0 \cdot \int_{-\infty}^{\infty} p(t-\tau) h(\tau) d\tau \right|^2 \right\} \\ &= E \{ |a_0|^2 \} E \left\{ \left| \int_{-\infty}^{\infty} p(t-\tau) h(\tau) d\tau \right|^2 \right\} \\ &= E \{ a_0^2 \} E \left\{ \left(\int_{-\infty}^{\infty} p(t-\tau) h(\tau) d\tau \right)^2 \right\} \end{aligned}$$

Symbols are random

P_d = Power of Data Symbols.

$$P_d = E \{ |a_0|^2 \}$$

Since $p(t)$, $h(t)$ are Fixed, these are Deterministic.

$$= \frac{P_d \left(\int_{-\infty}^{\infty} p(T-\tau) \cdot h(\tau) d\tau \right)^2}{\text{Signal Power}}$$