

PRINTING USING 'METAL X'

Dr. Amandeep Singh

Imaging Laboratory

IIT Kanpur




CONTENTS

- ✓ Optimize for printing
- ✓ Optimize for washing
- ✓ Optimize for sintering
- ✓ General strategies




OPTIMIZE FOR PRINTING

Identify Critical Dimensions




Maximize Bed Contact




OPTIMIZE FOR PRINTING

Reduce Supports




Optimize Your Production Workflow




MODIFY OVERHANGS TO OPTIMIZE SUPPORTS

Eliminates Supports




Chamfer small overhangs

Refer to Maximum Unsupported Overhang, pg 2




Teardrop XY holes to clear channels

Simplify Support Removal



Break up supports with chamfers on edges

Refer to Maximum Unsupported Overhang, pg 2




Add slits to separate segments




OPTIMIZE FOR WASHING

Shell Out Thick Parts




*Thicker part sections
increase wash time*




*Shell parts for a faster
wash time*

Wash Bowls Upside Down



*Slower wash time in printed
orientation*




*Faster wash time when
inverted*




TRIANGULAR VS. SOLID INFILL VS. THICK WALLS

Solid triangular infill wash time




Solid triangular infill dry time




OPTIMIZE FOR SINTERING




Reduce Stress Concentrations



Ensure Features are Well Balanced





Disable Part Rafts




STRATEGIC METAL PRINTING PRACTICES

Use Pins for Alignment Features




Separate Printed from Simple Features





STRATEGIC METAL PRINTING PRACTICES

Isolate Properties with Modular Features



DON'T PRINT YOUR HARDWARE



THANK YOU

